



Congratulations! You have purchased a stylish piece of Crosley Furniture. We strive to provide fine furniture products, built with quality materials. Please carefully follow the assembly instructions to ensure your furniture is assembled correctly to provide long lasting enjoyment.


Should you experience any missing or damaged parts, **do not return to the store.** Please contact us directly at 800-815-4796.

Care: Use a soft, clean cloth that will not scratch the surface when cleaning. The use of solvents is not necessary. Should you choose to use solvents, test in an inconspicuous area first to avoid damaging the finish. To clean, simply use a soft, clean cloth lightly dampened with water.






CAST ALUM. LOVE SEAT



CO6104-BK




PARTS LIST

<p>A</p> 	<p>B</p> 	<p>C</p> 	<p>D</p> 	<p>E</p> 
<p>Back 2 PCS</p>	<p>Seat 2 PCS</p>	<p>Left Side Frame 1 PC</p>	<p>Middle Side Frame 1 PC</p>	<p>Right Side Frame 1 PC</p>


HARDWARE LIST

<p>1</p> 	<p>2</p> 	<p>3</p> 	<p>4</p> 	<p>5</p> 
<p>Phillips Head Bolt (M6*30) 8 pcs</p>	<p>Spring Washer (M6) 8 pcs</p>	<p>Flat Washer (M6) 8 pcs</p>	<p>Nut (M6) 8 pcs</p>	<p>Nut Cap (M6) 8 pcs</p>
<p>6</p> 	<p>7</p> 	<p>8</p> 	<p>9</p> 	<p>10</p> 
<p>Short Bolt (M8*30) 4 pcs</p>	<p>Spring Washer (M8) 6 pcs</p>	<p>Flat Washer (M8) 12 pcs</p>	<p>Nut (M8) 6 pcs</p>	<p>Nut Cap (M8) 6 pcs</p>
<p>11</p> 	<p>12</p> 	<p>13</p> 		
<p>Wrench (M6 & M8) 1 pc</p>	<p>Long Bolt (M8*45) 2 pcs</p>	<p>Bolt Cap (M8) 4 pcs</p>		

Step 1: Attach Frames (C,D&E) to Seats (B) With Short Bolts (Part #6),Long Bolts(Part #12), Flat Washers(Part #8),Spring Washers(Part #7) & Nuts (Part #9).Note- Long Bolts (Part #12) will be used to attach the Middle Frame (D) & Short Bolts (Part #6) will be used to attach the Left & Right Side Frames (C & E).Cover M8X30 mm bolts (Part #6) with bolt caps (Part #13).Note - Do not fully tighten bolts at this time.




Step 2: Attach Back (A) to unit with Phillips Head Bolts (Part #1),Flat Washers (Part #3), Spring Washers (Part #2),and Nuts (Part #4).Tighten all bolts completely.Cover all Nuts (Part #'s 4) with Nut Caps (Part #'s 5).








CAST ALUM. RECT COFFEE TABLE
CO6201-BK




PARTS LIST

A 	B 	C 
<p>Leg 4 PCS</p>	<p>Top 1 PC</p>	<p>Stretcher 1 PC</p>

HARDWARE LIST

1 	2 	3 	4 	5 
<p>Cylinder Bolt (M8*35) 4PCS</p>	<p>Spring Washers (M8) 8 pcs.</p>	<p>Flat Washers (M8) 8 pcs.</p>	<p>Nuts (M8) 8 pcs.</p>	<p>Nut Caps (M8) 8 pcs.</p>
6 				
<p>Wrench (M6 &M8) 1 PC</p>				



Step 1: Place Top (B) upside down on a soft cloth.

Insert all Cylinder Bolts (Part #1) into the pre-drilled holes of Top (B).

Step 2: Attach two adjacent Legs (B) by inserting the Cylinder Bolts (Part #1) through the holes in Legs (A) by fitting the leg on top of the attached cylinder bolt. Secure the Legs (B) using Flat Washers (Part #3), Spring Washers (Part #2), and Nuts (Part #4). Note - -Tighten the Nuts (Part #4) only half way at this time using wrench (Part #6).

Step 3: Attach Stretcher (C) to the two attached Legs (A) with Flat Washers (Part #3), Spring Washers (Part #2), and Nuts (Part #4). Note - -Tighten the Nuts (Part #4) only half way at this time.

Attach the other two legs (B) to the Top (B) & Stretcher (C) using the same method as the first two legs. Tighten all Nuts (Part #4) completely.

Step 4: Cover all Nuts (Part #4) with Nut Caps (Part #5). Turn the table over to the upright position. Adjust the levelers on the bottom of the legs to level the table.

- | | | |
|-----------------|---|-----|
| ① Bolt |  | x 4 |
| ② Spring Washer |  | x 8 |
| ③ Flat Washer |  | x 8 |
| ④ Nut |  | x 8 |
| ⑤ Nut Cap |  | x 8 |




Figure 1
Flathead screw driver (not included)






Figure 2




CAST ALUM. CLUB CHAIR
CO6103-BK




PARTS LIST

<p>A</p> 	<p>B</p> 	<p>C</p> 	<p>D</p> 
<p>Back 1 PC</p>	<p>Seat 1 PC</p>	<p>Left Side Frame 1 PC</p>	<p>Right Side Frame 1 PC</p>


HARDWARE LIST

<p>1</p> 	<p>2</p> 	<p>3</p> 	<p>4</p> 	<p>5</p> 
<p>Phillips Head Bolt (M6*30) 4 pcs</p>	<p>Spring Washer (M6) 4 pcs</p>	<p>Flat Washer (M6) 4 pcs</p>	<p>Nut (M6) 4 pcs</p>	<p>Nut Cap (M6) 4 pcs</p>
<p>6</p> 	<p>7</p> 	<p>8</p> 	<p>9</p> 	<p>10</p> 
<p>Bolt (M8*30) 4 pcs</p>	<p>Spring Washer (M8) 4 pcs</p>	<p>Flat Washer (M8) 8 pcs</p>	<p>Nut (M8) 4 pcs</p>	<p>Nut Cap (M8) 4 pcs</p>
<p>11</p> 	<p>12</p> 			
<p>Wrench (M6 & M8) 1 pc</p>	<p>Bolt Cap (M8) 4 pcs</p>			

Step 1: Attach Side Frame (C & D) to seat (B) With Bolts (Part #6), Flat Washers (Part #8), Spring Washers (Part #7) & Nuts (Part #9). Note - Do not tighten Nuts (Part #9) fully at this time. Cover M8X30 mm bolts (Part #6) with bolt caps (Part #12).



Step 2: Attach Back (A) to unit with Phillips Head Bolts (Part #1), Flat Washers (Part #3), Spring Washers (Part #2), and Nuts (Part #4). Tighten all bolts of the chair completely. Cover all Nuts with Nut Caps (Part #5).





Limited Manufacturers Warranty

Crosley Furniture Products are warranted against defects in material and workmanship for a period of 90 days beginning from the date of sale. Should any parts be missing or defective, we will replace or repair the parts for a period of 90 days from the date of purchase.

Should you experience any missing or damaged parts, do not return to the store. Please contact us directly at 800-815-4796 from 9 AM to 5 PM (EST) Monday to Friday.

This warranty gives the purchaser specified legal rights in addition to any rights which may vary from state to state.

In accordance with the "Moss-Magnuson Warranty Act" of July 10, 1975, this is termed a "limited warranty" which in no way compromises Crosley Furniture's high standards of Quality and Workmanship.