

Model:  
CDD200, CDD201, CDD202

## Step 1

Attach back of arm by threading the attached dowel screw into the pilot hole until the arm is snug against the back leg.

## Step 2

Attach (4) 1-3/4 bolts thru the seat frame into the insert nuts on the arm supports

ROTATE  
CLOCKWISE

PILOT HOLE

ROTATE  
CLOCKWISE

INSERT  
NUTS

CDD200

CDD201

CDD202

- (1) CHAIR
- (2) ARM ASMB (RH/LH)
- (1) HARDWARE PACK

## TOOLS NEEDED



Qty.	Description
4	A - 1/4-20 X 1-3/4 WAFER SHCS
1	HDWPK-#8 SCREW PLUGS, 4X (EXTRAS)

