

MISSION MEDIA STAND



Thank you for purchasing our Mission Media Stand. Assembly of this product requires the use of a Phillips screwdriver and hammer. We have found it helpful to have second person assist with assembly.

STEP 1


Read through these instructions thoroughly before beginning assembly. We have found this to be of great value when first assembling this product.

STEP 2

Remove all parts and hardware from packing material. Wooden pieces should be placed on a non-abrasive surface (like the carton or carpet) to prevent damage to the finish.

STEP 3

Identify all parts using diagram at right



PARTS

- (1) Top Surface (A)
- (2) Shelf Assembly (B)
- (2) Side Assembly (C)


STEP 4

Identify and count hardware using diagram at right.



STEP 5


Align Side Assembly (C) with Middle Shelf and Bottom Shelf (B) so that the predrilled holes on the corners of the legs are facing in towards the center of Shelves (B) so that the larger countersunk holes are facing away. The diagram to the right shows the proper placement. A second persons assistance would be recommended to hold opposite side of Shelving (B) being worked on. **Do not fully tighten screws at this time.**



STEP 6

Align 2nd Side Assembly (C) with Middle Shelf and Bottom Shelf (B) as shown in **STEP 5**.


Fully tighten screws on both sides at this time.



STEP 7


Place Top Surface (A) as shown to the right so that holes in Sides (C) line up with holes in the corner brackets of Top Surface (A).

Tighten screws fully.



STEP 8

Finally, tap Wooden Plugs into holes with hammer to conceal screws.



CARE

Dust as needed with a soft cloth. Clean with damp cloth and mild solution of dish soap. Polish with soft cloth and polish that contains no pigments or silicone.



AMERICAN MADE FURNITURE www.manchesterwood.com

Product Support 1-800-660-6930