

- Make sure that all parts and hardware are present before assembly.
- Assemble on an a non-marring and level surface
- Do not completely tighten all nuts and bolts until the bench is fully assembled.

# WINDMILL TRIPOD TEXAS STAR

ITEM #: TX 93473, TX 93474 and TX 93476



### **STEP 1**

Connect top portion of Legs (A1) to the bottom part (A2) until it click into place.

Leg should face inwards, secure Top Mount Platform (B) to the top of legs (A1) with Screws (J)



STEP 4 Place the Directional Cap (E) on the Top Nount Platform (B), lock into place with the Needle (F).



**STEP 2** 

Affix Side Panet (C) into place between Windmill Legs (A), tighten with Bott (K), Flat Washer (L), Spring Washer (N), and Nut (N).



## **STEP 3**

Affix the Star Platform (D) on top of the Windmill Legs (A), and tighten with Screws (J). 

### **STEP 5**

Assemble the Windmill Head (G, H, I), make sure the Stop Nut (I) is screwed on well

Note: The front hole of the Fan Blades (H) is larger than the back hole



### **STEP 6**

Place the Windmill Head (G, H, I) on the Needle (F). Secure the windmill by inserting the Ground Stakes (0) through each hole at the base of each Legs



Congratulations on your assembly!





# Limited Warranty and Care Instructions

# LIMITED ONE YEAR WARRANTY (NON-TRANSFERABLE)

This product is covered under United General Supply's (UGS) one (1) year limited warranty. To the original purchaser of this piece of furniture, cooler, windmill, or accenssory, UGS warrants that it will be free from defects in material and workmanship for up to one year from the date of purchase under normal use and proper care.

Replacement of defective or missing parts will be sent at no charge to the customer for a period of 30 days from the date of purchase. UGS will no longer be responsible for missing parts or hardware 30 days after date of purchase. Freight, packaging, labor, or material charges to and from our customer service center is not covered under the warranty and is therefore the customer's responsiblity.

The limited warrany does not cover this piece of furniture, cooler, windmill, or accessory from commercial purposes, abusive use, damage by modification. freeze damage, rust, fading, and issues caused by improper care.

For minor defects or missing parts/hardaware, please contact customer service immediately upon purchase. Please do not return product to the store unless the damage is irrepairable. Customer service agent may help determine whether the damage is repairable and will provide further instructions.

For returns and refunds, please refer to your local store return policy with proof of purchase.

Proof of purchase (dated register receipt) will be required for warranty claims.

## PROPER CARE INSTRUCTIONS

If left untreated, wood will naturally weather. During long periods of non-use, store furniture or cooler in covered and dry place. For the least maintenance, place your furniture, cooler, or accessory under a covered area.

To preserve and maintain the original finish of Char-log/ Aspen log furniture, we recommend that a light lacquer coating be applied every 4 to 6 months depending on the seasons.

We recommended an exterior poly-urethane product that features a clear satin or semi-gloss finish and a fast drying process.

Customer Service may be reached Monday through Friday from 9:00a.m. to 5:00p.m. CST.

# HELPaugsco.com or 1-877-87LEIGH (53444)



DISTRIBUTED BY: UNITED GENERAL SUPPLY CO., INC. HOUSTON, TX 77036

www.LeighCountry.com