Intelligent Design™

Model: TGG48

- (1) Seat
- (1) Back
- (2) Sideframes
- (2) Glider Base Frames
- (2) Glider Cross Brace
- (1) Hardware pack


TOOLS NEEDED

4MM T-HANDLE HEX KEY

*NOTE: ALL FINE THREAD BOLTS (A) AND (B), WILL THREAD INTO EITHER THE TUBE OR AN INSERT NUT. COURSE THREAD SCREWS GO STRAIGHT INTO THE POLY


Step 1

Attach sideframes to seat using (4) 11/2" chair bolts. DO NOT TIGHTEN!!




Step 2

- Attach back to sideframes using (2) 21/4" chair bolts into the tube on top and (4) 21/2" screws on bottom
- Attach center of the back to the seat using (1) 21/2" screw



Step 4

-Attach glider base to bench with (4) 1½" chair bolts



QTY. DESCRIPTION

8

2

9

(INCLUDED)

- 1/4-20 X 1-1/2 WAFER SHCS

- 1/4-20 X 2-1/4 WAFER SHCS




C - .27 X 2-1/2 SOCKET WAFER A



Step 3

- -Tighten the 11/2" chair bolts from Step 1
- -Attach cross braces to the glider base frames with (4) 21/2" screws



Note: The direction of the pillars on the base. The angled edges should be facing the back when assembled

DETAIL A

ASSEMBLY INSTRUCTIONS

ALL HARDWARE IS COATED STAINLESS STEEL

11/30/2012